

Sliding Rack Side Mount Bracket

Sliding racks have always been an obstacle when installing the Steadyfast Stabilizer, but we have a good solution.

The Steadyfast Stabilizers locking bracket assembly cannot be mounted on the rack frame as it will not be solid. You can either place a set of scissor jacks (or move existing) ahead of the rack and mount the system there or use the [sliding rack bracket](#). The bracket bolts to the frame and extends below the rack allowing you to use the jacks at their existing location. It is installed on the inside or outside of the trailer frame. The drop below the frame is about 4 ¾ inches.

This bracket is designed to provide a solid mounting point for the locking bracket by attaching the bracket to the frame and bypassing the sliding rack when the sliding rack interferes.

- The bracket is bolted to the side of the frame with 4 self threading bolts.
- Its base plate extends below the sliding rack where the locking bracket can be directly bolted to it.
- Washers may be used as spacers if the bottom of the frame interferes with the installation.



Pictured below is an installation on the inside of a trailer frame with a covered bottom. It can be installed on the outside or the inside of the frame.

